







Assembly Instructions

Bravo



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.



- A Table Top
- B Table Legs
- C Leg Ring
- D  4pcs
- E  4pcs
- F  4pcs
- G  4pcs
- Allen Wrench

During assembly, **hand tighten** screws only. When all screws are in place, tighten completely.