

# eurø style™

## Assembly Instructions

Rubin-C



A x 8



B x 4




C x 1




Allen  
Wrench



D x 1  
Seat



E x 1  
Base



**PLEASE NOTE:** check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.

During assembly, **hand tighten** screws only. When all screws are in place, tighten all screws completely.