







euro style™

Assembly Instructions Tendy-B Bar

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.



A		4
B		4
C		4
D		4
E		1



During assembly, hand tighten screws only. When all screws are in place, then tighten completely.

CAUTION: 1. Do not use this chair as a step ladder.
2. Check for loose screws and tighten them regularly.